


Panel Capacities


Aluminium Collection

Sizes and dimensions

D Parts are also available for all sizes in this range.



The internal back wall of **A Parts** are designed to accommodate the head of an 8 or 9 gauge countersunk screw or bolt.



A+E Parts

Maximum part capacities E Parts

Optional extra spacers D Parts

	Metric	Imperial	Metric	Imperial
Small				
Max load per part	18 kgs	39.6 lbs	18 kgs	39.6 lbs
Max panel weight	36 kgs	79.2 lbs	36 kgs	79.2 lbs
Max panel thickness	4mm	.16"	4mm	.16"
Medium				
Max load per part	24 kgs	52.8 lbs	24 kgs	52.8 lbs
Max panel weight	48 kgs	105.6 lbs	48 kgs	105.6 lbs
Max panel thickness	8mm	.31"	8mm	.31"
Large				
Max load per part	30 kgs	66 lbs	30 kgs	66 lbs
Max panel weight	60 kgs	132 lbs	60 kgs	132 lbs
Max panel thickness	12mm	.47"	12mm	.47"
XL				
Max load per part	36 kgs	79.2 lbs	36 kgs	79.2 lbs
Max panel weight	72 kgs	158.4 lbs	72 kgs	158.4 lbs
Max panel thickness	16mm	.63"	16mm	.63"
XXL				
Max load per part	42 kgs	92.4 lbs	42 kgs	92.4 lbs
Max panel weight	84 kgs	184.8 lbs	84 kgs	184.8 lbs
Max panel thickness	19mm	.75"	19mm	.75"

IMPORTANT

- Maximum load per monomount should not exceed the maximum load per E Part.
- Maximum total load should not exceed the maximum panel weight.
- Maximum panel weight is fixed and does not increase with extra monomounts.

Installers must ensure that:



- Any of the limits detailed above are not exceeded.
- A Parts are securely fixed using screws or bolts that are strong enough to support the total load.
- When A Parts are mounted on brick, concrete or hollow walls etc then anchors, cavity fasteners, plugs or toggles designed for use with that type of wall are used.

Panel Capacities


Hybrid Collection

Sizes and dimensions

D Parts are also available for all sizes in this range.



The internal back wall of **A Parts** are designed to accommodate the head of an 8 or 9 gauge countersunk screw or bolt.



Important: Use approved wall anchors when required.

extra spacers (D Parts) are used to hold more panels and/or increase the standoff distance.

A+E Parts

Maximum part capacities E Parts

Optional extra spacers D Parts

	Metric	Imperial	Metric	Imperial
Small				
Max load per part	6 kgs	13.2 lbs	6 kgs	13.2 lbs
Max panel weight	12 kgs	26.4 lbs	12 kgs	26.4 lbs
Max panel thickness	4mm	.16"	4mm	.16"
Medium				
Max load per part	8 kgs	17.6 lbs	8 kgs	17.6 lbs
Max panel weight	16 kgs	35.2 lbs	16 kgs	35.2 lbs
Max panel thickness	8mm	.31"	8mm	.31"
Large				
Max load per part	10 kgs	22 lbs	10 kgs	22 lbs
Max panel weight	20 kgs	44 lbs	20 kgs	44 lbs
Max panel thickness	12mm	.47"	12mm	.47"
XL				
Max load per part	12 kgs	26.4 lbs	12 kgs	26.4 lbs
Max panel weight	24 kgs	52.8 lbs	24 kgs	52.8 lbs
Max panel thickness	16mm	.63"	16mm	.63"

IMPORTANT

- Maximum load per monomount should not exceed the maximum load per E Part.
- Maximum total load should not exceed the maximum panel weight.
- Maximum panel weight is fixed and does not increase with extra monomounts.

Installers must ensure that:


- Any of the limits detailed above are not exceeded.
- A Parts are securely fixed using screws or bolts that are strong enough to support the total load.
- When A Parts are mounted on brick, concrete or hollow walls etc then anchors, cavity fasteners, plugs or toggles designed for use with that type of wall are used.

Panel Capacities

Resin Collection

Sizes and dimensions

D Parts are also available for all sizes in this range.



A+E Parts

Maximum part capacities E Parts

Optional extra spacers D Parts

	Metric		Imperial	
Small				
Max load per part	6 kgs	13.2 lbs	6 kgs	13.2 lbs
Max panel weight	12 kgs	26.4 lbs	12 kgs	26.4 lbs
Max panel thickness	4mm	.16"	4mm	.16"
Medium				
Max load per part	8 kgs	17.6 lbs	8 kgs	17.6 lbs
Max panel weight	16 kgs	35.2 lbs	16 kgs	35.2 lbs
Max panel thickness	8mm	.31"	8mm	.31"
Large				
Max load per part	10 kgs	22 lbs	10 kgs	22 lbs
Max panel weight	20 kgs	44 lbs	20 kgs	44 lbs
Max panel thickness	12mm	.47"	12mm	.47"

IMPORTANT

- Maximum load per monomount should not exceed the maximum load per E Part.
- Maximum total load should not exceed the maximum panel weight.
- Maximum panel weight is fixed and does not increase with extra monomounts.

Installers must ensure that:

- Any of the limits detailed above are not exceeded.
- A Parts are securely fixed using screws or bolts that are strong enough to support the total load.
- When A Parts are mounted on brick, concrete or hollow walls etc then anchors, cavity fasteners, plugs or toggles designed for use with that type of wall are used.